



*Your Safety...Our Commitment*

---

### To Our Customers,

This guidance provides recommendations on the cleaning and disinfection of Heath manufactured equipment. We recommend you use personal protective equipment (PPE) when operating and cleaning your instrument to help reduce risk of infection and contact with viruses.

Approved cleaning methods are as follows:

- Instrument should be powered off when cleaning.
- Dampen a soft or disposable cloth and clean all organic material (visible soil or liquid) from the instrument prior to disinfection.
- Using a plastics compatible mild cleaning agent, disinfectant, or antimicrobial agent, spray a soft or disposable cloth to wipe the instrument and all accessories. Follow the manufacturer's guidelines for use of the cleaning or disinfectant agents.
- Allow the cleaning agent to stay on instrument per manufacturer time recommendations.
- Dampen soft cloth with clean water and wipe down all surfaces to remove any excess solution.
- **Do not** immerse or saturate the instrument with liquids to avoid damage to the electronics in the device.
- **Do not** use alcohol-based solutions.
- **Do not** use bleach solutions.
- **Do not** spray cleaning agents into open ports or vents on the instrument.

Should you have any additional questions or concerns, our Customer Service team is available at 713-844-1300 and [info@heathus.com](mailto:info@heathus.com).

---

For more information on general practices for disinfection, please refer to the [CDC's Environmental Cleaning and Disinfection Recommendations](#) or your companies policies and procedures.

---

